



LFSL

Brive-Souillac (Brive Dordogne Valley) Airport

BVE • NOUVELLE-AQUITAINE (CORRÈZE)

LAT 45°02'23"N LON 1°29'08"E ELEV 1016 ft PPR Confirm



AIRPORT REFERENCE POINT • 45.0397, 1.4856

RUNWAY 11/29 – 2,100 m × 45 m	CUSTOMS & IMMIGRATION On request – non-Schengen flights 24 hours' notice Tue–Fri; Sat–Mon by 10:00 on Friday
OPENING HOURS Airport daily 06:00–22:00 local. Tower generally 06:00–21:30 on weekdays; extension possible with 24 hours' notice.	HANDLING Brive Handling Service (airport)
PRIOR PERMISSION (PPR) Confirm with the airport	TELEPHONE +33 (0)5 55 22 40 00

Address Nespouls (13 km south of Brive-la-Gaillarde), **19600**. Nearest major city: Brive-la-Gaillarde, 13 km south of Brive-la-Gaillarde; A20 exit 53 (airport site).

Handling is compulsory for aircraft above 13.6 m wingspan. Jet A1 by truck during tower hours.

Facts taken from the airport's published information and the UK AIP, checked 30 Sep 2026. Hours, slots and permissions change: confirm with the airport or your operator before you travel. Information only, not operational advice.

privateairportguide.com
/airports/brive-souillac-brive-dordogne-valley-lfsl/