




LDDU

Dubrovnik Airport

DBV • DUBROVNIK-NERETVA COUNTY (SOUTHERN DALMATIA)

LAT 42°33'44"N **LO**N 18°15'56"E **ELEV** 527 ft **PPR** Required



RUNWAY 11/29 – 3,230 m × 45 m	CUSTOMS & IMMIGRATION Yes – border control on site. Crew must send the passenger and crew general declaration to the border police before departure.
OPENING HOURS Open 06:00–23:00 local in summer, 06:00–22:00 in winter. The General Aviation Terminal is open 06:00–22:00 local.	HANDLING Dubrovnik Airport Ltd (airport's own general and business aviation handling, VIP salon)
PRIOR PERMISSION (PPR) Required	TELEPHONE +385 20 773 301; +385 20 773 100

Address Dobrota 24, Čilipi, 20213. Nearest major city: Dubrovnik, 30–35 min to Dubrovnik (22.5 km); allow up to 1 hour in summer.

The General Aviation Terminal (GAT) is in the eastern part of the airport, separate from the main passenger terminal. It has a private VIP salon and VIP lounge; passengers are met at the aircraft. In the summer flight season the airport is slot-coordinated (Level 2) around the clock for ALL traffic, including private and business flights, so a landing slot must be agreed in advance through the airport's schedule coordinator (schedules@dbv.hr). The General Aviation Terminal opens 06:00–22:00 local; plan arrivals ...