




ESPA

Luleå Airport (Kallax)

LLA • NORRBOTTEN COUNTY

LAT 65°32'38"N **LON** 22°07'19"E **ELEV** 65 ft **PPR** Required



AIRPORT REFERENCE POINT • 65.5438, 22.1220

RUNWAY 14/32 – 3,350 m × 45 m asphalt	CUSTOMS & IMMIGRATION On request – arrange in advance
OPENING HOURS Mon–Fri 06:00–24:00, Sat 07:00–20:00, Sun 08:00–24:00 local. Permission needed 5 days ahead for civil flights.	HANDLING Swedavia Ground Handling (Luleå)
PRIOR PERMISSION (PPR) Required	TELEPHONE +46 10 109 48 00

Address Luleå Airport, Luleå, **972 54**. Nearest major city: Luleå, About 18 min by car to Luleå (routing estimate, free-flowing traffic).

Permission is required 5 days before arrival or departure for civil and cargo flights (scheduled, state, ambulance and similar flights are exempt); requests to lla.handlingrequest@swedavia.se. Shared with an air force base. About 7 km from the centre of Luleå (airport's figure).