




LKLT

Prague Letňany Airfield

PRAGUE

LAT 50°07'53"N LON 14°31'32"E ELEV 909 ft PPR Confirm



AIRPORT REFERENCE POINT • 50.1314, 14.5256

RUNWAY 05L/23R – 860 m x 23 m	CUSTOMS & IMMIGRATION On request – in writing; 24 hours' notice Mon–Fri, otherwise 48 hours' notice
OPENING HOURS Daily, daylight only: 09:00–19:00 local 1 May–1 Oct, then 09:00–17:00 (10:00–18:00 while clocks are on summer time).	PRIOR PERMISSION (PPR) Confirm with the airport
TELEPHONE +420 286 581 340 (airfield information); +420 725 912 020	

Address Letňany airfield, Prague 9. Nearest major city: Prague, Distance: about 7 km north-east of central Prague; Letňany metro station (line C) nearby.

A small daylight-only airfield in Prague suitable for light aircraft only. Avgas and Jet A-1 are listed as available. Customs for flights from outside the Schengen Area must be requested in writing in advance.