




BIRK

Reykjavík Airport

RKV • CAPITAL REGION (REYKJAVÍK CITY)

LAT 64°07'43"N LON 21°56'15"W ELEV 48 ft PPR Required



AIRPORT REFERENCE POINT • 64.1287, -21.9376

RUNWAY 01/19 – 1,567 m × 45 m asphalt	CUSTOMS & IMMIGRATION On request – arranged through the handling agent; private clearance inside the FBO
OPENING HOURS Daily 07:00–23:00 (weekends and holidays 08:00–23:00) local. Closed to all traffic outside these hours except emergencies.	HANDLING Reykjavík FBO (Iceland Aero Agents), ACE FBO
PRIOR PERMISSION (PPR) Required	TELEPHONE +354 424 5050; +354 551 1022 (Reykjavík FBO, 24 h)

Address Reykjavíkurlugvöllur, Reykjavík, 102. Nearest major city: Reykjavík, About 5 min by car to central Reykjavík.

Reykjavík FBO in Terminal 2 with lounge and private customs clearance; about 3–5 minutes from aircraft to a hotel reception. Contact +354 551 1022, ops@reykjavikfbo.is. ACE FBO +354 552 1611. Winter and summer hours are the same: no operations after 23:00, so plan departures and arrivals before then. Private aircraft must be registered in advance through the handling agent, and APU use is limited to 20 minutes; heated hangar space is limited and best booked early for May–September.